

D2212-S OMNIDIRECTIONAL VHF/VHF ANTENNA

WARNING!!

A QUALIFIED STRUCTURAL ENGINEER SHOULD BE CONSULTED PRIOR TO MOUNTING AN ANTENNA ON A TOWER OR SUPPORT STRUCTURE.

CLAMPING BLOCKS INSTALL

- 1) Insert clamping blocks at base of antenna aligned with holes in the side of clamp mount. The counter bored hole in the clamping blocks should align with the larger hole on its respective side of the clamp mount.
- 2) Slide the screw clamp through the supplied flat washer, the hole in the clamping mount and one of the clamping blocks then proceed to screw it into the second clamping block.
- 3) Repeat from other side using second clamping screw and flat washer.

