

AM-1 MOUNT

Installation

- 1) Join mounting plates using 3/4-10 x 2.00" bolt, nut and lockwasher. (see figure 1)
- 2) Attach mounting plates to antenna and mast using 3/4-10 U-bolts, nuts and lockwashers. (see figure 2)
- 3) Position antenna by rotating mounting plates, then secure in position using 1/2-13 x 1.5" bolts, nuts and lockwashers.

