

SAT-MP-320 MAST REPLACEMENT


MAKE SURE POWER IS DISCONNECTED PRIOR TO COMMENCING WORK OUTLINED IN THIS DOCUMENT

Package Contents

(1)Mast Assembly (1)3/32 Allen Key (3)#8 Split Lock Washer (3)#8-32 Screw



Start with antenna in deployed position



Push in button to release mast



Lower mast to remove tension





Unsnap helical from mast



ANTENNA



Using supplied Allen key remove all 3 screws from base of mast.



Slide Mast assembly onto antenna and align holes, ensure mast is inserted through center of helical



Pull helical up mast and snap it to arms

Please Note: A qualified structural engineer should be consulted prior to mounting an antenna on a tower or support structure.



Pull mast off antenna assembly



Using the 3 supplied screws and lock washers screw mast to antenna



Moving around antenna snap the rest of the helical to the arms, ensuring that the vertical straps are going straight up

Instruction Sheet 39129001 Rev. B 16/01/29



Take supplied mast assembly



Extend mast past push button so it is locked in place